

PRO DVX

THE ART OF DIGITAL VIEWING

Kiosk Browser Manual

Turn on your ProDVX Android Device and connect the device with internet. The device is now ready for the ProDVX Kiosk Browser. Insert the USB memorystick with the Kiosk Browser .apk file on it.


> Go to the overview by clicking on the circle in the middle.




> Click on ApkInstaller




> Click Install




> Click on USB Memory




> Click on the Kiosk Browser .apk file



> Click on Install




> The Kiosk Browser app is now installed. Click Open and the app will start running.



> The given url address will be shown



> To change the url address, press long on the upper left side of the display. It will show the url address after 10 seconds, in this case <http://www.prodvx.com>. Click on the url address to change it into the desired url address and click Go.



> Restart the unit


> It will now start the Kiosk Browser automatically to the last chosen url address

> To get out of the Kiosk Browser application:


- Slide with your finger from the upper right corner down to the lower right corner to the lower left corner to the upper left corner (an U shape along the edges of the display)



> To schedule a Reboot, press long on the upper left side of the display and click on Schedule Reboot.



> Set the time for the automatic reboot.



> To set a password, press long on the upper left side of the display and click on Edit Security. Click on Password to secure the device with a password.

