

Aansluitgegevens USB Keyboard Control iP2 (32) en iP4 (56)

Voor meer informatie: Zwart AV E: info@zwart-av.nl T: 0031505017340

INPUT	PRESET CODES	
	NORMAL CODES	CODES WITH SHIFT (hold 1 player start)
COIN 1	5	
COIN 2	6	
START 1	1	
START 2	2	ESC
1 RIGHT	R arrow	Tab
1 LEFT	L arrow	Enter
1 UP	U arrow	Key Below ESC (Volume, gamma, etc)
1 DOWN	D arrow	P (pause)
1 SW 1	L-ctrl	5 (Coin A)
1 SW 2	L-alt	
1 SW 3	space	
1 SW 4	L-shift	
1 SW 5	Z	
1 SW 6	X	
1 SW 7	C	
1 SW 8	V	
1 A	P	
1 B	ENTER	
START 1	1	
START 2	2	Esc
2 RIGHT	G	
2 LEFT	D	
2 UP	R	
2 DOWN	F	
2 SW 1	A	
2 SW 2	S	
2 SW 3	Q	
2 SW 4	W	
2 SW 5	I	
2 SW 6	K	
2 SW 7	J	
2 SW 8	L	
2 A	TAB	
2 B	ESC	
THE FOLLOWING CODES FOR THE I-PAC4 ONLY		
COIN 3	7	
COIN 4	8	
START 3	3	
START 4	4	
3 RIGHT	L	
3 LEFT	J	
3 UP	I	
3 DOWN	K	
3 SW 1	R-CTRL	
3 SW 2	R-SHIFT	
3 SW 3	ENTER	
3 SW 4	O	
3 SW 5		
3 SW 6		
3 SW 7		
3 SW 8		
4 RIGHT	U	
4 LEFT	V	
4 UP	Y	
4 DOWN	N	
4 SW 1	B	
4 SW 2	E	
4 SW 3	H	
4 SW 4	M	
4 SW 5		
4 SW 6		
4 SW 7		
4 SW 8		

